



TECHNICAL GUIDE

Clutch Central Unit (Lower/Upper Servo): Faults & Replacement

Diagnose, replace and maintain the heavy commercial vehicle clutch central unit (clutch booster & master cylinder): symptoms, torque values and field tips.

When the clutch on a heavy commercial vehicle turns stiff, the pedal drops away, or gears refuse to engage, the culprit is usually not the clutch itself but the clutch central unit sitting in the middle of the hydraulic-pneumatic chain that operates it. This arrangement, made up of the lower servo (clutch cylinder / clutch booster) and the upper servo (clutch master cylinder), converts the force the driver applies to the pedal into the power needed to disengage the truck's heavy pressure plate. In the field, the majority of "the clutch won't hold", "the pedal stays on the floor", and "it's leaking air" complaints trace back to these two components. This guide brings together the knowledge you need in the field — from identifying the servo type to diagnosing faults, and from removal and installation to service life.

E-E-A-T note: This document was prepared by the VADEN technical team, drawing on field experience with heavy commercial vehicle clutch hydraulics and pneumatic servo systems. The torque, pressure, and dimensional values given are typical reference ranges; for exact values always consult the vehicle's OE service manual. Last updated: September 2026. Component sizing is based on the relevant international standard family (ISO/EN/DIN/SAE) and the manufacturer OE specification.

What Is the Clutch Central Unit (Lower/Upper Servo)? Function and Operating Principle

The clutch central unit is the collective name for the arrangement of the upper servo (master cylinder), which converts the force the driver applies to the clutch pedal into hydraulic pressure, and the lower servo (clutch servo / clutch booster), which amplifies this pressure with support drawn from the vehicle's air system and transmits it to the clutch fork.

The operating principle is a force-transmission chain. When the driver presses the pedal, the piston inside the upper servo (master cylinder) pressurizes the hydraulic line (typically DOT-type brake fluid). This hydraulic pressure is carried through the pipe line to the lower servo. The lower servo combines this hydraulic force — which on its own would be insufficient — with compressed air of around 7–9 bar coming from the vehicle's air tank; its large-diameter pneumatic piston multiplies the hydraulic force and pushes the clutch fork (release fork), disengaging the pressure plate from the flywheel. This lets the driver disengage a heavy clutch with a relatively light pedal.

- **Upper servo (master cylinder):** Converts pedal force into hydraulic pressure; contains the reservoir, piston, and seal set.
- **Lower servo (clutch servo / booster):** Combines the hydraulic and pneumatic force and delivers it to the fork; houses the hydraulic cylinder, pneumatic cylinder, and control valve.
- **Control (relay) valve:** Opens/closes the air flow in proportion to the hydraulic signal.
- **Push-rod and fork linkage:** Carries the force to the clutch release bearing.
- **Seal, o-ring, and sleeve kit:** Provides sealing on both the hydraulic and pneumatic sides.

The Division of Labor Between the Upper Servo (Master Cylinder) and the Lower Servo

The upper servo can be thought of as a "signal generator": it initiates the force and determines the pedal feel. The lower servo is the "power amplifier"; it does the real heavy lifting with air support. That is why a softening pedal usually points to the upper servo, while incomplete clutch

disengagement or an air-leak sound usually points to the lower servo. Because the two parts work interdependently, when replacing one, the condition of the other and of the connecting line must always be checked as well.

Hydraulic-Pneumatic (Combined) System or Fully Hydraulic?

Most heavy commercial vehicles use a combined (hydraulically commanded, air-assisted) lower servo, because the clutch force is too high to be met by hydraulics alone. On some mid-segment and older-generation vehicles, a fully hydraulic or direct mechanical linkage may be seen. The servo type is the first determinant of the correct spare-part choice.

Type and Application Comparison

Feature / Type	Upper Servo (Master Cylinder)	Lower Servo (Clutch Booster)
Main function	Convert pedal force into hydraulic pressure	Combine hydraulic + air force and deliver it to the fork
Operating medium	Hydraulic (brake fluid)	Hydraulic + pneumatic (7-9 bar air)
Typical fault	Internal leak, pedal fade, drop in hydraulic level	Air leak, incomplete disengagement, external hydraulic leak
Mounting location	Near the pedal assembly, under the cab	Beside the transmission / clutch housing
Aftermarket brand context	Knorr-Bremse type, Wabco type	Knorr-Bremse type, Wabco type, Bendix type

Part number verification: Clutch servos vary by vehicle model, transmission type, and fork geometry; two servos that look alike visually may be incompatible in terms of piston diameter, stroke, or connection hole orientation. Before installation, always compare the vehicle's OE part number with the VADEN aftermarket reference; if in doubt, request verification using the chassis/engine details.

Fault Symptoms and Diagnosis

Clutch central unit faults usually develop gradually: first the pedal feel changes, then gear shifts become harder. The table below matches field complaints with likely causes and verification methods.

Symptom	Likely Cause	Check / Verification
Pedal softened, sinks to the floor and returns slowly	Upper servo internal seal leak, low hydraulic level	Check the hydraulic reservoir level and pedal free play; if pumping the pedal firms it up, there is air/a leak
Gears shift hard, the clutch does not fully disengage	Lower servo stroke insufficient, low air support	Observe fork movement and air pressure with the engine running; measure the fork stroke and compare it against the OE value

Symptom	Likely Cause	Check / Verification
Hissing / air-leak sound when the clutch is pressed	Lower servo control valve or sleeve leak	Check the valve and body connections with soapy foam; if the leak grows when the pedal is pressed, the valve is faulty
Hydraulic leak from the servo body	Worn o-ring / seal, cracked body	Wipe dry and press again; dampness around the push-rod indicates a seal leak
Clutch stiffens when air pressure drops	Lower servo air support disabled, valve blockage	Check the tank pressure and servo supply line with a gauge; the line may be restricted
Pedal stiffened, harder to press	No air support / valve locked, push-rod binding	Check the air supply line and valve freedom; inspect the mechanical friction points
Juddering on take-off and clutch shudder	Irregular servo stroke, fork play, air-hydraulic imbalance	Measure the free movement of the fork at idle; compare stroke and play values against the OE range

Tackle the Simple Things First: Level and Play

Before embarking on a complex diagnosis, check the hydraulic level, the pedal free play, and the air tank pressure. In a significant share of cases the problem stems from a low hydraulic level, misadjusted pedal play, or insufficient air pressure; it can be resolved without replacing the servo.

Internal Leak or External Leak?

An external leak is visible: there is dampness, dripping, or an air sound on the body. An internal leak is insidious; the pedal fades slowly with no visible leak outside, because the hydraulic fluid escapes back through the seal. A pedal that slowly sinks while held down typically points to an internal leak in the upper servo.

Assess the System as a Whole

If the clutch is not working, before blaming the servo directly, also assess the release bearing, the fork, the pressure plate / clutch disc, and the hydraulic line. Even with a healthy servo, a bent fork or a binding bearing can produce the same symptom. Correct diagnosis is only possible by following the chain from end to end.

Further reading

For a plain-language technical overview of this subject, see the reference article on [Wikipedia](#). Always confirm specific figures and procedures against the vehicle manufacturer service data.

Replacement / Installation Steps

Personal protective equipment (PPE) and safety: Before starting, move the vehicle onto level ground, stop the engine, switch off the ignition, and chock the wheels. Bleed off the air system safely (a blast of compressed air can cause injury). Brake fluid is harmful to skin and eyes and

damages paint; use gloves and goggles. The transmission/clutch area is heavy and has sharp edges; use appropriate lifting equipment.

- 1 Preparation and diagnosis confirmation:** Confirm that the fault really is in the servo using the methods in the diagnosis section; avoid unnecessary disassembly.
- 2 Make the system safe:** Switch off the ignition, bleed off the air pressure, consider disconnecting the battery, and clean the work area.
- 3 Drain the hydraulic fluid:** Drain the hydraulic fluid from the upper servo reservoir into a suitable container; prevent the fluid from being spilled onto the ground/into drains.
- 4 Disconnect the air line:** Mark and disconnect the lower servo's supply air line; protect the fittings and unions against contamination.
- 5 Separate the hydraulic pipe:** Disconnect the hydraulic inlet/outlet pipes; contain dripping fluid with a cloth and plug the lines.
- 6 Undo the mechanical linkage:** Disconnect the push-rod and fork linkage; note the adjustment dimension (stroke/play).
- 7 Remove the old servo:** Progressively loosen the mounting bolts and take the servo out; clean the mounting face and threads.
- 8 Check the new servo:** Compare the number, piston diameter, stroke, and connection geometry of the VADEN aftermarket part against the old part.
- 9 Install the new servo:** Seat the servo in place, tighten the bolts to the manufacturer's specified torque in a cross pattern; check the fork alignment.
- 10 Connect the lines and bleed:** Connect the hydraulic and air lines, fill the reservoir with suitable fluid, and fully bleed the air from the system.
- 11 Adjust and test:** Set the pedal free play and fork stroke to the OE value; with the engine running, verify gear shifts and the absence of leaks.

Points to Watch (Common Mistakes)

Don't set off without fully bleeding the air: Air remaining in the system makes the pedal spongy and prevents the clutch from fully disengaging. This can lead you to think the new part is faulty. Bleed the air fully, in the order the manufacturer specifies.

Wrong fluid and stroke adjustment: A fluid type unsuited to the system swells or hardens the seals. Also, if you skip the stroke/play adjustment, the clutch either fails to engage or stays permanently half-pressed, burning out the release bearing and the disc.

- **Dirty installation:** Letting dust/dirt into the hydraulic and pneumatic lines shortens valve and seal life; keep the connections clean.
- **Replacing only one part:** When replacing a worn lower servo, leaving in an upper servo or line whose health you are not sure of brings the problem back quickly.

- **Neglecting torque:** Tightening bolts by guesswork leads to a cracked body or a leak; always use a torque wrench.
- **Skipping the fork and bearing check:** A bent fork or a binding bearing will soon strain the new servo too.
- **Not verifying the air supply pressure:** A test done with low tank pressure makes even a healthy servo look "weak".

Technical Values and Check Points

The values below are typical/general reference ranges for heavy commercial vehicles; they vary by vehicle, transmission, and servo type. For the exact value, the vehicle's service manual must always be taken as the basis.

Parameter	Typical / General Reference Range	Note
Air system supply pressure	~7-9 bar (≈100-130 psi)	Lower servo air support works in this range; if low, disengagement weakens
Hydraulic line working pressure	~30-60 bar (higher at peak)	Varies with pedal force and piston diameter
Fork / push-rod stroke	~25-45 mm	Must be set to the OE value; if the stroke is insufficient it won't fully disengage
Pedal free play	~5-15 mm	Without play, the bearing is under constant load
Operating temperature range	~ -40 °C to around +80 °C	The seals and fluid must be selected for this range
Air leak tolerance	No leak should be visible under pressure by eye/foam	Pressure drop is monitored in a static test

Typical torque ranges for the mounting bolts are given below. These are general references; bolt diameter, class, and the OE instruction take priority.

Connection	Typical Torque Range	Note
Servo body mounting bolts (M10)	~40-55 Nm	Tighten in a cross pattern, progressively
Servo body mounting bolts (M12)	~70-95 Nm	The OE value is taken as the basis
Hydraulic pipe union	~15-25 Nm	Over-tightening damages the thread/cone
Air line fitting	~20-35 Nm	The sealing gasket is checked

Field tip: After fitting the new servo, with the engine at idle, press the clutch a few times and watch the fork movement by eye. If the stroke is clear, the return is fast, and there is no leak, the installation is sound. A spongy pedal is usually a sign of incomplete air bleeding.

- Verify the air tank pressure with a gauge; make sure there is no restriction in the supply line.
- Check with soapy foam that the servo does not leak either statically or with the pedal pressed.
- Measure the fork stroke and pedal free play and set them to the OE value.

- After bleeding the air, check and top up the hydraulic level again.
- In the first kilometers, re-inspect the connection torques and any possible leak.

Maintenance and Service Life

The clutch central unit is an assembly that works long and reliably with proper maintenance but fails suddenly when neglected. The main factors determining its life are hydraulic fluid quality, the cleanliness of the air system, and regular adjustment checks. Moisture and oil in the system air rapidly wear the valves and seals; that is why the air dryer and tank draining must not be neglected.

- **Hydraulic check:** The level and color should be monitored regularly; darkened/contaminated fluid should be renewed at the manufacturer's recommended interval.
- **Air system maintenance:** The air dryer cartridge and tank draining should be done regularly; the system should be kept dry against moisture.
- **Adjustment tracking:** Pedal play and fork stroke should be measured periodically and kept at the OE value.
- **Leak observation:** The area around the servo should be checked regularly for hydraulic and air leaks.
- **Connections and torque:** Connections that can loosen from vibration should be checked during servicing.

A well-maintained clutch servo serves trouble-free for many years; most early failures stem from dirty air, the wrong fluid, or a skipped adjustment. Regular checks protect both the part and the release bearing and pressure-plate/disc assembly connected to it.

If you have identified a fault in your clutch central unit, choosing the right servo is the first condition of service life and safety. The VADEN ORIGINAL Clutch Central Unit (Lower/Upper Servo) product family is manufactured with the correct piston diameter, stroke, and connection geometry for the hydraulic-pneumatic clutch systems of heavy commercial vehicles; by matching it to your vehicle's OE reference, you can select the right servo and achieve long-lasting, safe clutch performance.