



TECHNICAL GUIDE

Truck Radiator & Expansion Tank: Faults, Replacement & Care

Diagnose radiator and expansion tank faults on heavy trucks: overheating, coolant loss, pressure caps, correct replacement steps and safe technical values.

In a heavy commercial vehicle, most of the heat produced by the engine is expelled with the coolant; the component that releases this heat into the air is the radiator, while the vessel that lets the system breathe and balances its pressure is the expansion (coolant reservoir) tank. When a radiator weakens on a tractor unit during a long grade climb, or on a bus in stop-and-go city traffic, the result is not merely "the needle creeping up a little": overheating, cylinder head gasket damage, engine block warping and roadside breakdowns emerge as very expensive chain-reaction problems. This guide brings together the operating logic of the radiator and expansion tank for heavy diesel vehicles, along with fault diagnosis, correct replacement practice and safe technical values, in the language of the field.

This guide was prepared by the VADEN technical team, which has manufacturing and field-service experience in heavy commercial vehicle cooling systems, and its technical accuracy has been reviewed. The values here are general, safe references for common heavy commercial systems; for exact values specific to the vehicle and engine model, always rely on the relevant OE service manual (e.g. Behr/Mahle and the engine manufacturer's cooling system bulletins). Last updated: September 2026. Component sizing is based on the relevant international standard family (ISO/EN/DIN/SAE) and the manufacturer OE specification.

What Is the Radiator and Expansion (Coolant Reservoir) Tank? Function and Operating Principle

The radiator is a heat exchanger that cools the coolant by transferring the heat of the hot coolant coming from the engine to the airflow; the expansion (coolant reservoir) tank is a pressurized vessel that accommodates the coolant as it expands with heat, prevents air from entering the system and balances the pressure. As the engine warms up, the coolant circulates within the block until the thermostat opens; when the thermostat opens, the coolant is directed to the radiator, cools as it passes through the core with the help of the fan and travel air, and is then pumped back to the engine by the water pump. The system is closed and pressurized; the pressure raises the coolant's boiling point, delaying evaporation even under high load. In heavy diesel applications, this circuit is built around the operating logic of Behr and Mahle type OE radiators; the VADEN product family for this circuit covers components produced to OE-type dimensions, such as the expansion (coolant reservoir) tank, the expansion tank cover, the radiator pipe and cooling pipe, the radiator wedge (mount) and the fan ring.

The cooling circuit is not a single part but a chain of interconnected components:

- **Radiator core:** The actual surface that releases heat to the air, formed by the water tubes and the fins/louvers between them.
- **Side / top-bottom tanks:** The vessels that distribute the coolant to and collect it from the core; in aluminum-plastic types they are plastic, in all-metal types they are brass/aluminum.
- **Expansion / coolant reservoir tank:** The vessel that receives the expanding coolant, serves as the fill and bleed point of the system, and carries a pressure cap.
- **Pressure cap (radiator/tank cap):** The cap carrying a pressure valve that opens at a certain pressure (typically ~1 bar) and a vacuum valve that draws coolant back as the system cools.

- **Thermostat, water pump and fan:** Support elements that manage coolant temperature and flow rate, carry the heat to the radiator and increase the airflow.
- **Hoses, clamps and radiator mounts (rubber bushings):** The parts that provide the connection, vibration isolation and correct assembly.

Why are the pressurized system and the cap critical?

The closed cooling circuit operates under pressure because pressure raises the boiling point of the coolant. While pure water boils at 100 °C at sea level, with ~1 bar of extra pressure and the correct antifreeze mixture the boiling point is pulled significantly higher; this way the engine runs without forming vapor even under high load. The pressure cap establishes this balance: when the pressure exceeds the design limit, the valve opens and releases the excess pressure to the expansion tank/atmosphere, and when the engine cools, the vacuum valve draws the coolant back to prevent air from entering. A weak or wrongly rated cap can lower the system's boiling point and cause overheating even on a sound engine – which is why, despite being an inexpensive part, it is a critical safety element.

The function of the expansion (coolant reservoir) tank

As the coolant heats up, its volume increases. The expansion tank accommodates this increase in volume, houses the air gap (expansion space) in the system, and is generally the highest point where filling and bleeding are performed. In heavy commercial vehicles this tank is often of the pressurized type and its cap is located directly on it; when it cracks or its cap leaks, the system cannot hold pressure, the coolant level drops and the engine starts to overheat. The tank material is generally reinforced plastic resistant to the heat and pressure cycle; over the years this plastic can become brittle and crack at the seams.

Material types: aluminum-plastic, copper-brass and all-aluminum

Most modern heavy commercial radiators have an aluminum core + plastic side tank (joined by mechanical crimping/gasket) structure; they are light and efficient, but the gasket at the joint between the plastic tank and the core becomes a leak point over time. Classic copper-brass (soldered) radiators are heavy but more suitable for repair (soldering) and are still preferred in some heavy-duty/older fleet applications. All-aluminum welded types, on the other hand, are used in heavy-duty applications requiring durability. The table below summarizes type selection as a guide.

Radiator type	Structure	Strength	Weakness / caution
Aluminum core + plastic side tank	Mechanical crimping + gasket	Light, high heat transfer, low cost	Tank-core gasket line and plastic tank cracking are frequent faults
Copper-brass (soldered)	Soldered core + brass tank	Repairable (soldering), robust	Heavy, expensive to produce; solder fatigue can occur
All-aluminum (welded)	Aluminum core + welded tank	High durability, heavy duty	Difficult to repair; usually a complete replacement when damaged
Expansion/coolant reservoir tank	Reinforced plastic vessel	Light, integrated cap/level	Becomes brittle with heat cycling and cracks at the seam

The sole determinant in selecting a radiator and expansion tank is not the "same vehicle brand". The engine code, cooling capacity (core thickness/number of rows), inlet-outlet positions, connection diameters and tank type vary by vehicle variant. Do not order the exact equivalent without verifying it against the vehicle's engine code and the OE number of the original part that was removed.

Fault Symptoms and Diagnosis

Most cooling system faults fall under three main headings: **external leak (coolant loss)**, **insufficient cooling/overheating** and **pressure/air problem**. The critical point is this: the same symptom (for example, a continuously dropping coolant level) can originate from the radiator core, from a tank crack, from the cap, or from an internal leak. For this reason, diagnosis must be done by isolating the system with a pressure test before replacing any part.

Symptom	Possible Cause	Check / Verification
Coolant level keeps dropping, green/red trace underneath	Core/side tank crack, gasket line leak, loose hose-clamp	Apply a pressure test (leak-down) on a cold engine; visually inspect the leak point and trace with fluorescent dye
Engine overheats but there is no external leak	Internal blockage/scale-deposit, air lock, weak cap, insufficient antifreeze ratio	Map the core surface temperature (cold zone = blocked); test the cap pressure; verify bleeding
Constant bubbling in the expansion tank / air from the hose	Cylinder head gasket leak (exhaust gas mixing into the coolant), air lock	Apply an exhaust gas (combustion) leak test; observe the pressure behavior without opening the tank cap
Heater (cabin) blows cold, engine warms up	Air lock (air pocket), low coolant level, blockage	Fill and bleed the system by procedure; check the level and cap
Coolant puddle in the parking area on a cold engine	Expansion tank crack, cap/seal leak, lower hose	Inspect the tank and seams under pressure; look for wetness and crusting
Temperature needle fluctuates, steam/odor at the outlet	Weak pressure cap, low level, incipient internal leak	Measure the cap with a test device; check the level and run a combustion test
Core fins dented/blocked, no air passing from the front	External mud/insect/salt blockage, damaged louvers	Hold the core up to the light from the front; clean from the outside with low-pressure air/water

Distinguishing the external leak (coolant loss) symptom

A colored antifreeze trace and the crust left when it dries (crystallized residue) are the clearest signs of an external leak. However, a leak that evaporates on a hot engine may not be visible; therefore the most reliable method is to apply a hand-pump pressure test (leak-down) on a cold system. Pump the system up to a value close to the typical operating pressure and observe whether the pressure drops. If the pressure drops but there is no visible leak, the possibility of an internal leak (cylinder head/block) or in-core leakage comes to the fore. To locate the leak,

adding fluorescent (UV) dye to the system and scanning with a UV lamp is very effective in the field.

Distinguishing the insufficient cooling / overheating symptom

If the engine overheats while there is no external leak, the culprit is usually a loss of flow or heat transfer: partial internal blockage of the core with scale/deposits, the radiator being covered with mud and salt on the outside, an air lock, a weak cap or a wrong antifreeze ratio. While the engine is running, scan the core surface (with a non-contact thermometer); distinctly cold-remaining zones indicate that those tubes are blocked and therefore coolant is not passing through them. Also hold the front surface up to the light and check airflow; a core blocked on the outside cannot cool even if it is clean inside.

Distinguishing the pressure and air (air lock / internal leak) symptom

Persistent bubbling in the expansion tank, the system forming air again after filling, or a change in the color/odor of the coolant is a serious warning: this may indicate that exhaust gas is mixing into the coolant from the cylinder head gasket. To confirm this, a combustion (exhaust gas) leak test is used; a color change in the test fluid indicates that combustion gas is mixing into the coolant. An air lock (air pocket), on the other hand, most often results from incorrect filling/incomplete bleeding and is remedied with the correct bleeding procedure; if it persistently recurs, an internal leak should be sought underneath.

Could a coolant loss trace back to the air brake compressor?

On most trucks and buses the air brake compressor is water-cooled and connected to the engine's cooling circuit: coolant flows through water passages in the compressor's cylinder head and, depending on the design, through a separate cooling plate before returning to the circuit. What keeps that coolant apart from the compressed air is the compressor's head gasket, its O-rings and the casting itself. When the gasket burns through, or the cooling plate or the compressor head cracks, the two circuits open into each other, and the symptom depends on which side has the higher pressure at that moment. While the compressor is charging, the air side is at far higher pressure, so air is pushed into the coolant: the expansion tank shows bubbling that doesn't stop, system pressure climbs abnormally, the excess escapes by pushing coolant out past the cap, and the air trapped in the circuit can cause localized overheating. Once the compressor unloads, or after the engine is shut down while the cooling circuit is still hot and under pressure, the balance can reverse and coolant seeps into the air side instead. Draining the air tanks then brings out a milky, frothy fluid instead of ordinary condensate, and the **air dryer cartridge** is contaminated with antifreeze. Fixing the leak does not clean them: the contaminated cartridge and tanks have to be dealt with separately.

The practical way to tell this apart from a leak at the engine's own cylinder head gasket is to watch the bubbling against what the compressor is doing. With the vehicle chocked and the engine idling, bleed down the air tanks, let the compressor charge for a good while, then wait until the tanks are full and the compressor unloads. If the bubbling grows while the compressor is charging and eases or stops once it unloads, suspect the compressor side. A leak at the **engine's cylinder head gasket** doesn't follow the compressor at all; it changes with engine load and puts combustion gas into the coolant, which is why the combustion leak test described above changes color on an engine head gasket leak but generally shows no reaction to air coming

from the compressor. Make this observation on a warm engine without opening the cap, looking through the tank's translucent body or at the end of the overflow hose. Replacing the compressor's cooling plate and its gasket is covered in the [compressor cooling plate](#) and [compressor repair and gasket kit](#) guides.

Reading these findings together with gauge behaviour speeds up the diagnosis; how the way the needle climbs narrows down the cause is explained in the [engine overheating in heavy-duty trucks](#) guide.

Further reading

For a plain-language technical overview of this subject, see the reference article on [Wikipedia](#). Always confirm specific figures and procedures against the vehicle manufacturer service data.

Replacement / Installation Steps

The steps below are a general sequence for heavy diesel (truck/tractor unit/bus); always rely on the torque, capacity and procedure values in the vehicle's service manual.

Use personal protective equipment: wear safety goggles and gloves. When the cooling system is hot it is under pressure; opening the cap on a hot engine leads to serious burns from spurting boiling water and steam. Begin operations **only after the engine has cooled completely** and open the cap slowly, stopping at the first detent. Antifreeze is toxic; do not release the drained fluid into the environment/drain, collect it appropriately.

- 1 Secure and cool the system:** Stop the vehicle on level ground, chock it, shut off the engine and wait for it to cool completely. Open the cap only after the system has cooled and the pressure has been released.
- 2 Drain the coolant:** Open the radiator lower drain plug (or the lower hose) and collect the coolant in a suitable container. If there is a block drain, use it as well. Open the top cap to ease draining.
- 3 Mark the connections:** Photograph and label the upper-lower hoses, expansion tank hoses, heater lines, oil cooler/transmission cooler lines if present, and the fan/shroud connections.
- 4 Remove the hoses and clamps:** Loosen the spring/screw clamps and separate the hoses. Do not force hardened hoses; if necessary, cut them off and replace them with new ones. Plug the open ports.
- 5 Separate the fan shroud and supports:** Remove the fan guard/shroud, the viscous fan or electric fan connections if present, and the radiator upper mounting/support elements.
- 6 Remove the radiator:** Carefully lift the radiator up off its rubber bushings (mounts). Do not rub the core and fins against other parts; use appropriate lifting for heavy types.

- 7 Prepare and compare the new radiator/tank:** Place the new part side by side with the old one and verify that the connection positions, core thickness, inlet-outlet diameters and mounting points match exactly. Remove the shipping plugs.
- 8 Renew the mounts and bushings:** Replace the radiator lower rubber bushings (mounts) if they are crushed/cracked. A mount with degraded vibration isolation cracks the joints of the new radiator in a short time.
- 9 Position and connect the new radiator:** Seat the radiator on its mounts and tighten the upper supports to the manufacturer's torque. Always use **new hoses and new clamps**; align the clamps with the hose neck mark and tighten them properly. Verify that the fan-shroud gap is equal everywhere and that the fan does not touch the shroud.
- 10 Fill with the correct mixture:** Prepare the antifreeze type specified by the manufacturer (e.g. a specification suitable for the engine such as long-life OAT/silicate-free) in the appropriate ratio (typically 50/50) and, if possible, with demineralized water, then fill slowly. The wrong type or ratio leads to corrosion and deposits.
- 11 Bleed the air and run a pressure test:** Use the bleed screw/point if present; open the heater valve. Start the engine and warm it until the thermostat opens, top up the level and completely expel the air lock. Then, on a cold system, verify all connections and the cap for leaks with a hand-pump pressure test.

Points to Watch (Common Mistakes)

Handing over the system without properly bleeding it is the most common and most expensive mistake. An air lock remaining inside causes the engine to overheat locally and damages the cylinder head gasket, even if the coolant level appears normal. After filling, be sure to warm the engine until the thermostat opens and complete the bleeding.

Never open the pressure cap on a hot engine. Boiling water and steam under pressure spurt out and cause severe burns. Open the cap only after the engine has cooled, stopping at the first detent to release the pressure.

- **Using the wrong antifreeze type/ratio:** Mixing fluids of different chemistry (e.g. IAT with OAT) can lead to gelling and deposits; too low an antifreeze ratio weakens boiling and freezing protection together with corrosion protection. Always use the specification suitable for the engine and the correct ratio.
- **Refitting an old/weak cap:** A cap that does not hold pressure causes overheating even on a sound radiator. When replacing the radiator, test or renew the cap as well.
- **Reusing a hardened hose and an old clamp:** An aged hose and a loosened clamp will leak in a short time. When replacing, renew the hose and clamp together.
- **Installing with a crushed mount:** A degraded rubber bushing transmits vibration to the radiator and cracks the plastic tank/gasket line. Do not neglect the mounts.
- **Force-cleaning the core surface:** High-pressure water or a stiff brush flattens the thin aluminum fins and reduces heat transfer. Clean at low pressure and from the inside out.

- **Replacing parts without measuring the leak:** Before pinning overheating directly on the radiator, run a pressure test, a cap test and, if necessary, a combustion test; the real culprit is often the cap, an air lock or an internal leak.

Technical Values and Check Points

The values below are general/safe references for common heavy commercial vehicle cooling systems. Critical values such as cap pressure, operating temperature, antifreeze ratio and torque **vary by vehicle and engine model**; for the exact figure, always rely on the relevant service manual.

Parameter	Typical / Safe Reference	Note
Pressure cap opening pressure	~0.9–1.1 bar (~13–16 psi)	Varies by the manufacturer that designed the system; marked on the cap
Normal operating temperature (coolant)	~82–95 °C	Varies with the thermostat and load
Thermostat opening start	~79–88 °C	Varies by engine family
Warning/critical upper temperature	~100–105 °C and above	When reaching this band, reduce the load and stop
Antifreeze / water mixture ratio	Typically 50/50 (approx. –35 °C protection)	Do not go outside the 40–60% band; adjusted to the climate
Pressure test (leak-down) hold	No significant drop at a value close to the cap pressure	Applied on a cold system
Expansion tank level	Between MIN–MAX when cold (usually lower-middle)	The level rises when hot; read it when cold

The cap pressure (~1 bar), operating temperature and 50/50 mixture values above are consistent with the widely accepted general references for heavy commercial diesel cooling systems; the exact opening pressure is marked on the cap itself, and the antifreeze specification (e.g. ASTM/engine manufacturer approval) takes priority according to the vehicle manufacturer. The values may vary by region, climate and engine variant; the service manual and the information on the cap/label should always be taken as the basis.

Typical installation torque and connection tightening reference

The tightening values of the radiator support bolts, fan shroud and hose clamps vary by bolt size, class and connection type. The values below are only a **general reference**; for the exact torque, always use the vehicle manual.

Connection (size / type)	Typical torque range	Note
M6 / 8.8 (shroud, small support)	~8–10 Nm	Do not crush plastic/thin-sheet connections
M8 / 8.8 (radiator support)	~22–25 Nm	General reference

Connection (size / type)	Typical torque range	Note
M10 / 8.8 (main mount/foot)	~43–48 Nm	General reference
Screw hose clamp	~4–7 Nm (by feel by hand, not with a torque gun)	Over-tightening cuts the hose; align the clamp with the neck mark

Tighten the radiator support bolts gradually, not to full torque in one go, and do not load stress onto the body/core body. On radiators with plastic side tanks, over-tightening and forced assembly crack the tank-core joint. Do not over-tighten the hose clamps; sealing is achieved by correct seating and a clean surface, not by the clamp crushing the hose.

Quick check points in the field

- Watch the temperature needle/gauge while the engine is running; deviation and fluctuation from the normal band is an early warning.
- On a cold engine, verify the expansion tank level is between MIN–MAX; if it keeps dropping, look for a leak.
- Hold the front face of the core up to the light and check airflow and fin blockage; external blockage is a frequently overlooked cause.
- Measure the pressure cap with a test device; if the opening pressure is low or the vacuum valve does not hold, renew it.
- Squeeze the hoses by hand: if there is excessive softening, swelling or cracking, replace them. Review the clamp alignment and tightness.

Maintenance and Service Life

The service life of the radiator and expansion tank depends largely on two things: the chemical quality of the coolant and the cleanliness of the core. Both directly affect internal corrosion/deposits as well as external heat transfer. A routine that keeps preventive maintenance simple extends the life not only of the radiator but also of the thermostat, water pump and cylinder head gasket in the background.

- **Daily / pre-trip:** Check the level on a cold engine, watch the gauge, and visually check for leaks/wetness and blockage on the front face of the core.
- **Periodic (during PM services):** Measure the antifreeze concentration and condition (color, cloudiness, pH/protection); scan the hoses-clamps; test the cap; inspect the seams of the expansion tank under pressure.
- **Coolant change:** Renew the antifreeze within the manufacturer's interval (longer for long-life types, shorter for conventional) with the correct specification and ratio. Mixed/contaminated fluid causes corrosion and deposits.
- **Core cleaning:** Clean the front face at low pressure, from the inside out (mud, insects, salt, leaves). Take care not to flatten the fins; crushed louvers reduce heat transfer.

- **Electrolysis/corrosion check:** Poor chassis grounding and degraded antifreeze lead to electrolysis corrosion in aluminum cores. If in doubt, check the grounding and the antifreeze protection level.

If recurring leakage from the side tank gasket line, a crack in the plastic tank/reservoir, internal blockage with scale-deposits and irreparable fin damage on the outside are seen together, then it is time to replace the radiator. Partial repair (soldering/gluing) remains temporary in most heavy commercial applications; a complete replacement is generally more reliable and more economical overall. In this case, renewing the pressure cap, the upper-lower hoses and the worn mounts as well significantly extends the life of the new radiator. The thermostat and water pump in front of the radiator and the cylinder head gasket behind it are parts of the same system; to prevent a recurrence of the fault, evaluate these components together as well.

After correct diagnosis and a clean installation, the decisive factor is that the radiator and expansion tank you fit meet the cooling capacity, pressure resistance and dimensional compatibility of the OE-type design. The VADEN Cooling System product family — expansion/coolant reservoir tank and tank cover, radiator pipe and cooling pipe, radiator wedge and fan ring, together with the water pump, thermostat and fan group — has been developed for heavy diesel trucks, tractor units and buses, to meet the safe technical values and field expectations in this guide; it is enough to select the model suitable for your needs together with the vehicle and engine matching, evaluating the cooling circuit as a whole.

Shop this part: [Radiator](#)